
# Cyber Power

4-Pack: 8-Outlet Surge Protector (6 AC & 2 USB Ports)

## **MP1028WW**



## **USER MANUAL**

## **FEATURES**

read this manual.

1. Surge Protected Indicator Illuminated when the surge protection feature is working properly.

**CONGRATULATIONS ON YOUR PURCHASE** 

manual explains the features and operation of

the MP1028WW. Please take a few moments to

Thank you for selecting the CyberPower

MP1028WW 4-Pack Surge Protector. This

- Ground Indicator LED Illuminated when the Ground protection feature is working properly.
- Pivoting Grounded Outlets (6) Pivoting outlets for ease of use and convenience, fits standard-sized plugs.
- USB Charging Ports\*

Connect and charge up to two (2) USB devices using the surge protected USB charging ports. \*USB outlets cannot be used as a USB hub. This

## **SPECIFICATIONS**

- Model Number: MP1028WW
- Outlets: 6 Standard Outlets, 2 USB Charging Ports
- Surge Protection: 1,200 Joules
- Electrical Rating: 125 V/15 A/1875 W

device does not transfer data.

- USB Charging Rating: 5 V/2.4 A total
- $\bullet$  UL Clamping Voltage: UL 1449  $3^{rd}/400\,V$  (H-N, N-G), 500 V (H-G)
- Maximum Peak Current: 60,000 A
- 3 AC Lines Protected: H-N: 30,000 A, H-G: 15,000 A, N-G: 15,000 A; (The maximum surge possible on household Wiring is 6,000 volts)
- Response Time: Less than 1 nanosecond
- Attenuation: Up to 32 dB
- EMI/RFI Filtration: 150 kHz to 100 MHz

## CAUTION

TO REDUCE THE RISK OF ELECTRIC SHOCK - Use only in dry locations and only indoors. **DO NOT** plug into another relocatable power tap. DO NOT "daisy chain" surge protectors. **DO NOT** use with any aquarium equipment. DO NOT use if properly grounded outlets are not available. **DO NOT** install this device if there is less than 10 meters (30 feet) or more of wire between the electrical outlet and electrical service panel. DO NOT use for medical or life support equipment. This device features an internal protection that will disconnect the surge protective component at the end of its useful life, but it will maintain unprotected power to the load.

### TROUBLESHOOTING

- If the grounded indicator does not light when you plug in the surge protector, move the surge protector to a different grounded three-prong AC outlet. If it still does not light, return the product to the retailer for assistance. If the surge protector appears to be working properly, your outlets may not be properly grounded and need to be repaired by a professional electrician. If the grounded indicator turns o" after a period of use, the surge protection has been depleted. Replace your surge protector.
- If the protected indicator does not light, the surge protector's AC lines are no longer protected from surge. The surge protector may have received a power surge or spike beyond its specified limits that overloaded the protection circuitry and rendered it inactive. The surge protector has protected your connected equipment as designed, but it will not protect against future surges, and spikes. It should be replaced.

## TECHNICAL SUPPORT

Please contact our Tech Support Department with installation, troubleshooting, or general product questions.

- Phone: 1-877-297-6937
- Visit: CyberPowerSystems.com/support
- Hours of Operation:

Monday - Friday 7:00am - 6:00pm CST

## LIMITED LIFETIME WARRANTY AND CONNECTED EQUIPMENT GUARANTEE

Read the following terms and conditions carefully before using the CyberPower CSP600WSURC2 (the "product"). By using the product, you consent to be bound by the terms and using the product, you consent to be bound by the terms and conditions of this limited lifetime warranty and connected equipment guarantee (together referred to as this "warranty"). IF YOU DO NOT AGREE TO THE TERMS AND CONDITIONS OF THIS WARRANTY, YOU SHOULD RETURN THE PRODUCT FOR A FULL REFUND PRIOR TO USING IT.

Who is providing this warranty, and what does it cover? Cyber Power Systems (USA), Inc. ("CyberPower") provides this limited lifetime warranty. It only covers the original purchaser and ends if you no longer own the product. This warranty covers defects in materials and workmanship in the product under normal use and conditions. It also covers equipment connected to the product and damaged because of the failure of the product. This warranty covers the product and connected equipment for aslong as you own the product.

- How do you open a connected equipment claim?

  1. Call us at (877) 297-6937, or write to us at Cyber Power Systems (USA), Inc., 4241 12th Ave. E., STE 400, Shakopee MN 55379, or send us an email at claims@cpsww.com within 10 days of the occurrence for instructions.
- When you contact CyberPower, identify the product, the purchase date, and the item(s) of connected equipment. Have information on all applicable insurance or other resources of recovery/payment that are available to the initial customer and request a claimnumber.
- You must provide a dated purchase receipt (or other proof of the original purchase) for the CyberPower unit and connected equipment. You also need to provide a description of the damage to your connected equipment.

  4. Pack and ship the product to CyberPower and the item(s)
- Pack and ship the product to CyberPower and the item(s) of connected equipment, a repair cost estimate for the damage to the connected equipment, and allclaim forms that CyberPower provides to you. Show the claim number on the shipping label, or include it with the product. You must prepay all shipping costs. You are responsible for packaging and shipment, and you must pay the cost of the repair estimate.

## What will CyberPower do to correct problems?

What will CyberPower do to correct problems?

CyberPower will inspect and examine the product. If the product is defective in material or workmanship, CyberPower will replace it at CyberPower's expense, or CyberPower will refund the full purchase price you paid for the product (purchase receipt showing price paid is required). If the product foiled to protect any equipment plugged into it, we will also send you forms for making your claim for the connected equipment. We will repair or replace the equipment that was damaged because of the failure of the product or pay you the fair market value (NOT REPLACEMENT COST), of the equipment at of the time of the damage. We will use Orion Blue Book, another third-party valuation guide, eBay, Craigslist, or othersource to establish that amount. Our maximum liability is limited to \$75,000 for the MP1028WW.



## Who pays for shipping?

We pay shipping when we send items to you; you pay when you send items to us.

## What are some things this Warranty does not cover?

- THIS WARRANITY DOES NOT COVER: ANY SOFTWARE
  THAT WAS DAMAGED, SOFTWARE THAT NEEDS TO BE
  REPLACED DUETOTHE FAILURE OF THE PRODUCT, OR
  ANY DATA THAT IS LOST AS A RESULT OF THE FAILURE.
  THIS WARRANITY DOES NOT COVER THE RESTORATION
  OF DATA OR RECORDS, OR THE REINSTALATION
  OF SOFTWARE.
- This warranty does not cover: misuse, modification, operation or storage outside of the environmental limits of the product or the equipment connected to it. It does not cover damage while in transit or in storage; if there has been improper operation or maintenance, or use with items not designed or intended for use with the product, such as laser printers, appliances, aquariums, medical, or life rupport devires. life support devices, etc.

## What are the other limitations?

The sole and exclusive remedies of the initial customer are

- Ine sole and exclusive remedles of the initial customer are those provided by this warranty.

  1. This warranty does not apply unless the product and the connected equipment were connected to properly wired and grounded outlets (including compliance withelectrical and safety codes of the most current electrical code), without the use of any adapters or other connectors.
- The product must have been plugged directly into the power source. The equipment connected to the product must be directly connected in the product, not "daisy chained" together in serial fashion with any extension cords, another product, or device similar to the product, surge suppressor, or power tap. Any such installation voids the warranty. the warranty.
- The product and connected equipment must have been used properly in a suitable environment, in conformance with any applicable license, instruction manual, or warnings.
- The product must have been used at all times within the limitations on the product's maximum rated wattage.

### Where can I get more information? Contact us at:

Cyber Power Systems (USA), Inc. 4241 12th Avenue East Suite 400 Shakopee, MN 55379; Call us at (877) 297-6937; Send us an email message at claims@cpsww.com.

## PRODUCT REGISTRATION

Prompt product registration assures coverage under the limited lifetime warranty, and also allows the opportunity of notifications for product enhancements, upgrades, and other announcements.

Registration is quick and easy. Go to the Product Registration Page at CyberPowerSystems.com/registration.

## CONTACT INFORMATION

Cyber Power Systems (USA), Inc. 4241 12th Avenue East Suite 400 Shakopee, MN 55379

Toll-free: 1-877-297-6937 | CyberPowerSystems.com

## CONFORMANCE APPROVALS



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that

accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no augrantee that interference will not

Interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause hamful interference to radio or television reception, which can be determined by turning the equipment o" and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver isconnected.
  Consult the dealer or an experienced radio/TV technician
- for help

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A WARNING: This product can expose you to chemicals including bisphenol A (BPA) and styrene (ABS), which is known to the State of California to cause productive harm and cancer, Formore information, go to www.P&SWarnings.ca.gov.



Please join CyberPower in caring for the environment by recycling this manual.



This device is manufactured using environmentally-safe procedures in compliance with the Restriction of Hazardous Substances (RoHS) directive.



UL Listed to U.S. and Canadian Safety Standards UL 1449. This product is listed to applicable U.S. and Canadian safety standards by Underwriters Laboratories Inc.



© 2020 Cyber Power Systems (USA), Inc., All rights reserved. All other trademarks are the property of their respective owners. CyberPowerSystems.com